

C-900 Pull Head Installation Procedures



Step 1 – Align pull head with the end of the C-900 PVC pipe.



Step 2 – Install pull head over the top of the C-900 PVC pipe. Install the pull head where PVC pipe extends the end cap of the pull head.



Step 3 – Drill a hole through the PVC pipe. The drill bit should be the same diameter (1/2") as the pull head drill hole.



Step 4 – Install the slotted roll pin into the pin hole. The roll pin should extend through both pull head and the PVC pipe.



Step 5 – After installing the first roll pin continue to install all the remaining roll pins.